

Quick Repeater Commands

Use those commands for your Ottawa repeater

To access the command line use <https://meshcore.io/flasher> top right console, or connect to the repeater with you companion using admin console in the repeater contact on your companion:

1. `set path.hash.mode 2`
2. `set advert.interval 240`
3. `set flood.advert.interval 47`
4. `set flood.max 16`
5. `set loop.detect moderate`
6. `region def yow|* on|* onqc|* can|* na`
7. `region allowf *`
8. `region default yow`
9. `region save`

Revision #1

Created 2026-10-14 00:55:45 UTC by Shawn

Updated 2026-10-14 01:07:01 UTC by Shawn